

CANDLELIGHT

Design: Philip Bro Ludvigsen

Philip Bro Ludvigsen graduated from the Danish Design School in 1989 and has since taught at the Danish Design School and at the National Institute of Design in India. Since the early 1990s, he has designed many classic lamps for LE KLINT, all with modern variations of Kaare and Esben Klint's famous pleated lampshades.

Philip Bro Ludvigsen er uddannet på Skolen for Brugskunst i 1989 og har undervist på Danmarks Designskole og National Institute of Design, India.

Philip Bro Ludvigsen har siden starten af 1990'erne designet adskillige klassiske lamper for LE KLINT, som alle er moderne variationer af Kaare og Esben Klints berømte foldede skærme.



LE KLINT

Egestubben 13-17 · 5270 Odense N
leklint@leklint.dk · www.leklint.com

CANDLELIGHT



LE KLINT

Instruktion
Instructions Manual

Instruktion for CANDLELIGHT

INDHOLD

Lampe med glas og indbygget LED lys. Opladerkabel.

VEDLIGEHOOLD

Lampen holdes ren ved aftørring med en fugtig klud og tørres efter med en tør klud. Brug ikke sprit eller andre stærke rengøringsmidler på lampedelene. Håndtaget er lavet i egetræsfinér som enten har en klar lak eller en sort lak. Basen er lavet i egetræ for den træfarvede udgave og i sortlakeret kork for den sorte udgave. Glasset sidder løst og kan let afmonteres for yderligere rengøring med midler der er egnet til glas. Vær ekstra opmærksom på at der ikke kommer fugt ned i selve lyset, da elektronikken kan tage skade.

LYS


Lampen leveres med en indbygget LED lyskilde. Lyskilden er udviklet specielt så det ligner en lille flamme der står og brænder. Lampen er genopladelig, læs om dette nedenfor. Selve lyset er lavet i rigtig voks og er derfor følsomt overfor høje varmegrader. Voksen bliver blød ved ca. 50 grader. Derfor anbefales det at flytte lampen væk fra stærkt sollys og undgå at benytte den i meget varme rum/steder så som havestuer og vindueskarme i sommerperioden. Lysfarven varierer mellem 1900-2100 Kelvin. Lyset udsender 3 lumen og kan lyse i 200 timer inden behov for genopladning. Når det er ved at være tid til at oplade lampen, vil man opleve at lyset falder i intensitet som et tegn på at den snart mangler strøm.

UDPAKNING & MONTAGE

Lampen pakkes ud af papindlæggene i kassen. Den sættes til opladning og er herefter klar til brug. På modsatte side af opladerindgangen sidder tænd/sluk knappen, den nederste af de 3 messingdetaljer. Læs hele instruktionen ang. opladning, vedligehold og lyset inden lampen tages i brug.

OPLADNING

Lampen oplades med det medfølgende kabel som tilsluttes via USB stikket til en oplader. Det kan f.eks. være en oplader fra en telefon eller direkte i computeren. Oplades med en 5 V/1 A enhed. En fuld opladning tager 4 timer. Mens lampen oplades blinker lyset på en svagere styrke for at vise den oplader. Når den stopper med at blinke er den ladet op.



Instructions for CANDLELIGHT

CONTENTS

Lamp with glass and built-in LED light. Charge cable.

MAINTENANCE

The lamp is kept clean by wiping with a damp cloth and then dried with a soft cloth. Do not use alcohol or other harsh cleaners on the lamp parts. The handle is made of oak veneer which has either a clear lacquer or a black lacquer. The base is made of oak for the wooden version and in black lacquered cork for the black version. The glass is loosely attached and can be easily removed for further cleaning. Pay special attention to the fact that moisture does not get into the light itself, as the electronics can be damaged.

LIGHT

The lamp comes with a built-in LED light source. The light source is specially designed to look like a small flame that is burning. The lamp is rechargeable, read about this below. The light itself is made of real wax and is therefore sensitive to high degrees of heat. The wax can get soft at approx. 50 degrees. Therefore, it is recommended to keep the lamp away from strong sunlight and avoid using it in very warm areas such as gardens and window sills during the summer period. The light color varies between 1900-2100 Kelvin. The light emits 3 lumens and can glow for 200 hours before recharging is needed. When the lamp needs to be recharged, the light intensity is reduced. It shows that it needs power.

UNPACKING & ASSEMBLY

Unpack the lamp from the cardboard inserts in the box. Charge the lamp before use. On the opposite side of the charger input sits the power button - see drawing. Read the full charging, maintenance, and light instructions before using the lamp.

CHARGING CANDLELIGHT

Charges with a 5 V / 1 A unit. Use the supplied cable to charge the lamp to connect the USB end to a charger, either from a mobile phone or a computer. Your CANDLELIGHT is fully charged when the flame stop moving. A full charge takes 4 hours. While the lamp is charging, the light flashes with a low intensity to show it is charging. When it stops blinking it is fully charged.

