

# Vejledning for Model 172 XL/XXL

Læs venligst instruktionerne, før du samler lampen. Vi anbefaler at man er to personer til at samle denne lampe for forebyggelse af skader. Ophængningssystemet skal fastgøres til lampen inde i kassen.

## INDHOLD

Model 172 pendler leveres med el-ophæng i enten messing eller stål, inkl. tre-benet holder.

## UDPAKNING

1. Fjern og udpak først el-ophænget, som er pakket i siderummet af kassen.
2. Fjern alle papstøtter og transportbeskyttelse fra indersiden og rundt om lampen, mens den stadig er i kassen.

## VEDLIGEHOLD

Til rengøring af lampen/skærmen kan du bruge enten en blød støvbørste, en let fugtig klud eller en støvsuger med børstehoved.

## LYSKILDE

Vi anbefaler at bruge en LED-pære for at skærmen ikke bliver for varm.

Vælg en lyskilde i forhold til den mængde lys, du ønsker, der hvor lampen hænges op.

Vi anbefaler: 172XL: E27, 15 W, ca. 1560 lumen

172XXL: E27, 15 W, ca. 1560 lumen

NB: Maks. watt er 35 W LED for begge modeller. Vær opmærksom på, at der skal være minimum 3 cm mellem lyskilden og skærmmaterialet.

## MONTAGE

3. El-ophænget har en tre-benet tværstang/holder med 3 kroge fastgjort til metalrøret. Tværstangen kan placeres højt eller lavt på metalrøret, så du kan placere lyset i lampen, hvor du ønsker det.
- 4a. Indvendigt i lampen er der en hvid metalring, hvor tværstangskroge fastgøres.
- 4b. Sænk el-ophæng med fatning ned i lampen.
- 4c. Vip og sænk forsigtigt tværstangskroge i lampen, og træk derefter tværstangen op, så den bærer den hvide metalring.
- 5a. Løft el-ophænget med din anden hånd for at forhindre, så det ikke falder af.
- 5b. Placer den ene hånd under midten af tværstangen, medens den anden holder fast i el-ophænget. Løft lampen ud af kassen. Du har muligvis brug for hjælp her. Det anbefales at man er to personer til dette.

**Lampen er nu klar til ophængning.**

**Indsæt og montér lyskilde.**

**Din lampe er nu klar til brug.**

# Instruction for Models 172 XL/XXL

Please read the instructions before you attempt to assemble the lamp. We recommend 2 persons to assemble this lamp for safety and damage prevention. The hang up system must be attached to the lamp inside the box.

## CONTENTS

Model 172 pendants are available with a choice of brass or steel, electrical hang-up systems with attached crossbar.

## UNPACKING

1. First, remove and unpack the electrical hang up system, that is packed in the side compartment of the box.
2. Remove all cardboard supports and protective coverings, from inside and around the lamp, while it is still in the box.

## MAINTENANCE

To clean the lamp/shade, you can use either a soft dust brush, a slightly damp cloth or a mild setting on the vacuum.

## LIGHT SOURCE

We recommend using an LED light bulb to avoid excessive heat inside the shade.

Choose a light source in relation to the amount of light you desire where the lamp is hung.

We recommend: 172XL: E27, 15 W, approx. 1560 lumen

172XXL: E27, 15 W, approx. 1560 lumen

NB: Max. wattage is 35 W LED for all models. Be aware that there must be a minimum of 3 cm between the light source and the shade material.

## ASSEMBLING

3. The electrical hang-up system has a crossbar with 3 hooks attached to the metal tube. The crossbar can be positioned high or low on the metal tube, so you can have the light inside the lamp, where you desire.
- 4a. Around the inner top edge of the lamp, is a white metal ring where the crossbar hooks will attach to
- 4b. Lower the socket head down inside the lamp.
- 4c. Carefully tilt and lower the crossbar hooks, down inside the lamp, then pull up the crossbar so it attaches itself to the white metal ring.
- 5a. Hold the electric wire with your other hand to prevent the hang up system from falling
- 5b. Place one hand under the centre of the crossbar and the other firmly holding the electrical wire and lift the lamp out of the box. You may need some assistance here.

**The lamp is now ready to be attached to the ceiling electrical outlet**

**Insert and fit light bulb.**

**Your lamp is now ready for use**



# MODEL 172 XL / XXL

Design: Poul Christiansen

Poul Christiansen trained at the Royal Danish Academy of Fine Arts' School of Architecture.

Between 1969 and 1987 Poul Christiansen brought innovative and exciting dimensions to LE KLINT's lamp shades. Prior to his involvement the shades had been folded in pleats and in straight lines across the pleats. Poul Christiansen discovered that folding in mathematical curves gave the lamp shades beautiful and unique sculptural shapes.

Poul Christiansen er uddannet på Det Kongelige Danske Kunstakademis Arkitekt-skole.

Poul Christiansen tilføjede i perioden 1969-87 nye spændende dimensioner til LE KLINT-skærmene. Indtil da var skærmene foldet i plisséer samt i lige linjer tværs over plisséerne. Imidlertid opdagede Poul Christiansen at foldning efter matematiske kurver, gav lampeskærmene nogle helt enestående og smukke skulpturelle former.



Polished steel / Poleret stål



Brushed brass / Børstet messing

# LE KLINT

MADE IN ODENSE, DENMARK SINCE 1943

Egestubben 13-17 • 5270 Odense N

[www.leklint.com](http://www.leklint.com) • [leklint@leklint.dk](mailto:leklint@leklint.dk)

# MODEL 172 XL / XXL



# LE KLINT

Instruktion  
Instructions Manual